8566_1408 8700_ed5.qxp 06/12/05 12:31 Side 4

Contents:

1. Construction **4**
2. Battery installation **5**
3. Charging **6**
4. Key functions **7**
5. Turning the handset ON/OFF **9**
6. Making a call **10**
6.1 Receiving calls **12**
6.2 During conversation **13**
6.2.1 Volume regulation **13**
6.2.2 Microphone mute **13**
6.2.3 Transferring the call to another handset **13**
7. Menu structure **14**
7.1 Using the alphanumeric keyboard **15**
7.2 The key functions **16**
7.3 Profile set up **17**
7.4 Profile functions **19**
7.5 Menu subscription and login **21**
7.5.1 Create subscription **22**
7.5.2 Login **23**
7.5.3 Auto login **24**
7.5.4 Remove subscription **26**
7.5.5 Change startup text **26**
7.6 Battery capacity **27**
7.7 Redial **28**
7.8 Book **30**
7.9 External services **32**
7.10 MSF Functions **33**
7.11 Mail/Textmessages **34**
7.12 Speed dial **38**
8. Date and Time function **39**
9. Language **40**
10. Advanced settings **41**
11. Shortcuts **44**
12. Information **45**
12.1 Error tree **45**
12.2 Error information **46**
12.3 Warranty **46**
12.4 Technical information **47**

VoIPon www.voipon.co.uk sales@voipon.co.uk Tel: +44 (0)1245 808195 Fax: +44 (0)1245 808299

8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 5

1. Construction

Headset Connector (only KIRK 4040)

Display with backlight

MENU key

Key for internal calls (not used on KIRK Wireless Server)
Loud speaking (only KIRK 4040)

Keyboard LOCK (Menu*)

Recall key (MAIL key)

SILENT (Menu#)

ON/OFF HOOK key- also used as turn ON key

CONFIRMATION key - MUTE microphone. MUTE ringer when ringing. Long key press turns OFF

Left arrow key, Redial Menu from standby text

LED

Alarm key

Right arrow key, save number. Phone book Menu from stand-by text

Volume up/down

8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 6

2. Battery installation

The battery is connected to the handset when it is shipped from the factory. To change the battery you must unscrew the plate on the rear of the handset to access the battery compartment.

To remove the battery cover, use a normal screw driver. Insert it into the small crack behind the blind cover and break to open the handset.

Please note: The product label, including the CE logo, can be found in the battery compartment.

VoIPon www.voipon.co.uk sales@voipon.co.uk Tel: +44 (0)1245 808195 Fax: +44 (0)1245 808299

8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 7

3. Charging

During normal operation, it takes approximately 3 1/2 hours to charge the handset from fully discharged to its full capacity. Place the handset in the charger. When the handset is turned on, the display shows the charging status in line 3. For correct charging be sure the room temperature is between 0°C and 25°C. Do not place the handset in direct sunlight. The battery has a built-in heat sensor which will stop charging if the battery temperature is too high.

It is necessary to recharge the battery when the display shows “BATTERY LOW”, or if it can not be turned on. The LED flashes at a low frequency while charging and lights constantly when the charging is finished. The display goes back to normal mode when fully charged.

When the handset is placed in the charger it will not vibrate, and B-answer is inactive. If the battery is fully discharged, up to 10 min. may pass before charging begins and the handset can be turned on. When the charger begins the charging, status is shown in the 3rd line of the display and the LED flashes slowly.

8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 8

4. Key Functions

The handset has 21 keys:

Two keys are placed at the right side for volume control. Press upper or lower key to change the volume. Each key-press turns volume one step up/down.

“MENU”	- Go to menu structure or exits the menu structure. (Escape or “NO”)
” < ”, “REDIAL”	- Menu: left, Cursor left, after a digit: delete last digit. Long press: delete all From standby text: Redial Menu
” > ”, “BOOK”	- Menu: right, Cursor right, After a digit: Store number in telephone book From standby text: Telephone book read
“✓”, “MUTE”	- Confirmation (“YES”) or jump to next level in the menu. In off hook: Mute microphone In on hook: Mute ringer. Long key press turns the handset OFF

VoIPon www.voipon.co.uk sales@voipon.co.uk Tel: +44 (0)1245 808195 Fax: +44 (0)1245 808299

8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 9

"INT"	- If residential systems: Internal calls off hook (not used on KIRK Wireless Server) Turns loudspeaking on and off in off hook (only KIRK 4040)
"R"	- If off hook: Recall. If on hook: Read or write message
"☎"	- On hook/off hook and turn ON
" * "	- * (Change from pulse to DTMF on KIRK Wireless Server), Long = pause (-), extra long: change from pulse to DTMF (a "T" appears in the display, GAP standard)
"0-9"	- Digits or letters in alphanumeric mode (names and messages)
" * "	- *, Choose uppercase or lowercase letters in alphanumeric mode

8566_1408 8700_ed5.qxp 07/12/05 12:48 Side 10

5. Turning the handset ON/OFF

ON: Press -key for 1/2 second.
When the handset is turned on the symbol is shown in the lower left corner of the display, if the handset is subscribed to a system. (For subscription, see Chap. 7.5.1)

OFF: Press the ✓-key (MUTE) for 3 seconds

Please note: When the handset has been outside the coverage area, it can take up to 30 seconds before the handset is back on the system after re-entering the coverage area.

VoIPon www.voipon.co.uk sales@voipon.co.uk Tel: +44 (0)1245 808195 Fax: +44 (0)1245 808299

8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 11

6. Making a call

For making or receiving calls the handset has to be subscribed to a system (shown in display) (see Chap. 7.5.1).
Press the -key, the -icon in the display will flash until connection is established.
Dial the number.

Pre-dial:
Press the number to dial (long press on * will make a pause, if necessary).
Press the -key, the -icon will flash until the connection is established.

Telephone book:
Press the > -key (BOOK) to enter the telephone book.
Search for the number either by using the < or > -keys or by pressing the first letter in the name by using the digits 1 – 9 (see Chap. 7.2).
Press the -key, the -icon will flash until the connection is established.

8566_1408 8700_ed5.qxp 07/12/05 12:51 Side 12

Redial:
Redial / CLIP (CLIP = Calling Line Identification Presentation) stack:
Press the < -key (REDIAL) to enter the redial/CLIP stack.
Search for the number by using the < or > -keys, redial numbers are marked with “REDIAL” or name and clip numbers are marked either with “CLIP” or the name of the person who called and the LED is on.
Press the -key, the -icon will flash until the connection is established.

Using the handset in residential systems: (not on KIRK Wireless Server)
Internal call post-dial:
Press the INT-key, the -icon in the display will flash.
Dial the number of another handset on the base station, the -icon will flash until the connection is established.

Internal call pre-dial: (not on KIRK Wireless Server)
Press the number of another handset on the base station.
Press the INT-key, the -icon will flash until the connection is established.

VoIPon www.voipon.co.uk sales@voipon.co.uk Tel: +44 (0)1245 808195 Fax: +44 (0)1245 808299

8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 13

Please note: If the Date and Time function is supported, then date and time of the incoming or outgoing call is shown in the CLIP/Redial stack on the 4th line of the display. See Chap. 8 for more information.

Speed dial:
See Chap. 7.12 and Chap. 10 for more information about speed dialing.

6.1. Receiving calls

If the phone rings, the call can be answered by pressing the ☎ -key.
When ringing the LED flashes fast, and the display shows the CLIP (if presented). If it is an external call (or if no CLIP) the display shows “INCOMING CALL”.

It is possible to stop the ring signal without answering the call. Press MUTE (✓) and the ring signal is muted. Display shows: “RINGER MUTED“.

8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 14

6.2 During conversation

6.2.1 Volume regulation:
Use the two keys placed at the right side of the handset for volume control.

6.2.2 Microphone mute:
Press the ✓-key (MUTE), “MIC. MUTED” is showed in the display.
Press the ✓-key (MUTE) to enable the microphone again.

6.2.3 Transferring the call to another handset:
Press the R-key, and dial new number.

Press the ☎-key and the call is transferred to the other handset.

8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 15

7. Menu structure

Pressing the MENU-key, enters or exits the menu structure. It has to be used if a “NO” or “CLEAR” is wanted in the menu structure.
Pressing the ✓-key, jumps to a lower level in the menu. When the lowest menu level is reached, it will store the setting and jump to a higher level. It has to be used if a “YES” is wanted.



The Phone book Menu, Redial Menu and Mail Menu can be accessed directly. The Phone book Menu by pressing the > -key (BOOK), the Redial Menu by pressing the < -key (REDIAL), and the Mail Menu by pressing the R-key (MAIL).

8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 16

7.1 Using the alphanumeric keyboard

The normal dialling keys (0-9) are used for writing the name to be placed in the telephone book. By pressing the keys a certain number of times the related letters or digits will appear in the display. Spaces are made by using the 0-key. Key * changes between uppercase and lowercase letters. The arrows will move the cursor. Left arrow is also used for deleting (hold for 1 sec.) = delete. New letters can be inserted.

Change of key press and pauses lasting more than 1 second automatically moves the cursor to next position.

Please note: 4th line of the display shows the possible alphanumeric keys.

8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 17

7.2 The key functions

Key	Capital letter	Small letter
1	? ! 1 - + * / = & ( ) % ¿ ¡	? ! 1 - + * / = & ( ) % ¿ ¡
2	A B C 2 Ä Å À Á Ã Æ Ç	a b c 2 ä å à á ã æ ç
3	D E F 3 È É Ê Ë	d e f 3 è é ê ë
4	G H I 4 Ì Í Î Ï	g h i 4 ì í î ï
5	J K L 5	j k l 5
6	M N O 6 Ñ Ö Ò Ó Ô Õ Ø	m n o 6 ñ ö ò ó ô õ ø
7	P Q R S 7 ß	p q r s 7 ß
8	T U V 8 Ü Ù Ú Û	t u v 8 ü ù ú û
9	W X Y Z 9	w x y z 9
0	[Space] , . 0 : ; _ “ ‘ ^ ~	[Space] , . 0 : ; _ “ ‘ ^ ~
*	A→a	A→a
#	# @ E $ £ ¥ § < > { | } [\ ]	# @ E $ £ ¥ § < > { | } [\ ]

8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 18

7.3 Profile set-up

To set-up the handset press MENU. You are now able to switch between the different settings. Press ✓ when you find the setting you wish to change (or see). Change the setting according to your needs, confirm with ✓ and you automatically go to the next setting. Press MENU to finalize the setup.

8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 19

Profile set-up (fig)



8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 20

7.4 Profile functions

RINGERTONE: Scroll through the 9 different ringertones using < and >. Confirm with ✓.
RINGER VOL: Turn the volume up and down using < and >. Confirm with ✓.
KEY CLICK: Turn the volume up and down using < and >. Confirm with ✓.
VIBRATOR: Can be turned on/off using < and >. Confirm with ✓ (vibrator only works on KIRK 4040).
B-ANSWER: Can be turned on/off using < and >. Confirm with ✓. When turned on, the telephone automatically goes off hook when ringing. If subscribed to a KIRK solution it automatically goes on hook when calls are terminated. B-answer is inactive when handset is placed in the charger.
REMARK: Automatic on-hook is only reliable under defined conditions related to the interface settings between the KIRK Wireless Server and the PBX.
START VOL: Start volume can be adjusted using < and >. Confirm with ✓.

VoIPon www.voipon.co.uk sales@voipon.co.uk Tel: +44 (0)1245 808195 Fax: +44 (0)1245 808299

8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 21

OUT OF RANGE: The out of range indication can be turned on/off using < and >. Confirm with ✓. With the out of range indicator turned on, a beep will appear when the telephone is moving out of range of the base station, and "OUT OF RANGE" will appear in the display.
AUTO KEYLOCK: The auto keylock function can be turned on/off using < and >. Confirm with ✓. With auto keylock turned on the handset will automatically lock the keys after 30 seconds. Press MENU ✱ to activate the keys again.
LANGUAGE: see Chap. 9.
BACKLIGHT: Can be turned on/off using < and >. Confirm with ✓.
ADVANCED: see Chap. 10.

8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 22

7.5 Menu subscription and login



8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 23

7.5.1 Create subscription

To make subscriptions, the system must allow subscriptions to be made. Some systems also require an Access Code (AC). If more than one system currently permits subscription, you will need to know the ID of the system to which you wish to subscribe. Access Codes and system ID's will be provided by the system administrator.
Choose the "SUBSCRIPTION CREATE" function to subscribe to a new system (see Chap. 7.5/7.5.4).
Use the < and > keys to scroll between the ID's of the different systems available.
During subscription the handset will search for free positions and perform subscription on the first free position.
An alternative position can be choosen using < or >. Enter the AC (if required) using the keyboard, and press ✓.
If the subscription was successful, the startup text will be replaced by the standby text given into the system by the system administrator and (((•))) is shown in the display. If not, the subscription has failed and the procedure must be retried.
If the handset is already subscribed to 10 systems, you will have to remove a subscription before creating a new subscription (see Chap. 7.5.3).

8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 24

7.5.2 Login

The handset can be subscribed to 10 different systems enabling you to use the same handset on 10 different systems.
If you would like to change to another system, use the Login Menu to connect to another system number.
The actual chosen system is marked with a ★.
To change to another system use < or > and press ✓ to confirm.
To be able to log on to a system, subscription to the system has to be established (See Chap. 7.5.1).
Under LOGIN/SELECT LOGIN only subscriptions will be shown. Free positions will not be shown.



8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 25

7.5.3 Auto login

The handset can be subscribed to 10 different systems.

If a handset is subscribed to two or more systems, you can use Auto Login A to change between the systems automatically. The selected system is marked with an “A”.

Please note: Auto login A should only be used in separate systems without overlaps. If a handset looses signal from the system (the display showing “OUT OF RANGE”), then after 20 seconds the handset will start searching for an alternative system available from the Login list and automatically change to this system. Changing between systems can only take place while on hook. Any call will be dropped when changing to an alternative system.

8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 26

If a handset is subscribed to two systems only, you can use Auto Login B to change between the two systems automatically. The selected system is marked with a “B”.

Please note: Auto login B can be used in separate systems which are overlapping each other. As soon as the handset has measured a low radio signal 5 times in succession, it will start up the Auto login B procedure and change to an alternative system if available. Changing between two systems can only take place while on hook. Any call will be dropped when changing to an alternative system.

8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 27

7.5.4 Remove subscription

Subscriptions can be removed from the system in use and from the 9 other systems (if connected). Removing a subscription requires a password. Password is factory set at 0000. If the system in use is removed, it is necessary either to select one of the remaining systems or to subscribe to a new one. If one of the systems not chosen is removed, the handset remains connected to the system in use.

7.5.5 Change startup text

The startup text is predefined as e.g. ”KIRK telecom” as factory default. This can be changed by using the following procedure: Press ✱✱✱✱, BOOK, ✓ and enter the new startup text using the keyboard followed by ✓. It is possible to insert 24 characters.

8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 28

7.6 Battery capacity

In the Battery Menu it is possible to see the remaining battery capacity. For reading the correct capacity, the handset has to be removed from the charger for at least one hour. Press MENU and use the < or > keys to reach the Battery Menu. Press ✓ to enter the menu, and you can see the current status of the battery capacity. Press ✓ to return to the menu system or press MENU to quit.
The indication on the display is not necessarily an exact reflection on the remaining speech time, but only an indication of the voltage on the battery.



VoIPon www.voipon.co.uk sales@voipon.co.uk Tel: +44 (0)1245 808195 Fax: +44 (0)1245 808299

8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 29

7.7 Redial

The handset has maximum 10 redial numbers and 10 Caller ID/MISSED CALL numbers placed in the same stack. Each number is only represented once. Enter the Redial Menu by pressing the < -key (REDIAL) from the standby text. Repeated presses at the < -key turn backward through the dialled numbers and CLIP numbers (from newest to the oldest). The > -key moves in the opposite direction. It is also possible to reach the Redial Menu in the main menu. Numbers are named “REDIAL”, ”CLIP” or with the name.
The LED will flash slowly and the display shows “MISSED CALL” if a new number has arrived in the CLIP stack. Press the < -key (REDIAL) to see the missed call.
If no number (no clip) is represented by a call only the LED will flash slow afterwards.
If you want to delete a ”CLIP” or a ”REDIAL” you scroll to the name/number and press ✓ twice.
The name/number is now deleted. If number is stored, it is moved to the telephone book. You can also delete all name/numbers using the “DELETE ALL?” function.
It is possible to edit the CLIP or REDIAL numbers. Find the number you wish to edit and press the digits you want to add to the number, e.g. prefix = O.

8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 30

The Redial and CLIP stack Menu (fig)



VoIPon www.voipon.co.uk sales@voipon.co.uk Tel: +44 (0)1245 808195 Fax: +44 (0)1245 808299

8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 31

7.8 Book

Storing a number (max. 24 digits) in the telephone book is done by pressing the number to be stored (in on hook), then press the > -key followed by the ✓-key. The book can store up to 200 numbers with name. Typing of the name and a confirmation is required. After storing the telephone will go back to standby mode. If the display shows "MEMORY FULL", it is necessary to delete one or more numbers from the telephone book.
(See menu structure page 31)



8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 32

Read BOOK numbers: The telephone book is entered by pressing > (BOOK). For quick-search: press the first letter of the name (using 1-9)(see Chap. 7.2). Call the displayed person by pressing the key. It is also possible to reach the Phone book Menu in the main menu. Viewing and editing the telephone book can also be done while in conversation.



VoIPon www.voipon.co.uk sales@voipon.co.uk Tel: +44 (0)1245 808195 Fax: +44 (0)1245 808299

8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 33

7.9 External services

External services are features placed in the main system, and only available if the handset is subscribed to a KIRK solution. Under External services can be found; “View Clip Stack”, “Delete Clip Stack” and “Local Phone Book”. The Local Phone Book is a common phone book for all handsets subscribed to the actual system, and all handsets subscribed to the system are listed in the phone book. Additional numbers can be added to the phone book by the system administrator.

8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 34

7.10 MSF Functions

MSF Functions are special functions, which are based on MSF (Message Service Function). The functions require special software in the main system.

8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 35

7.11 Mail/Text Messages

Available in systems configured with the possibility of sending text messages

At the reception of a text message the envelope icon ✉ appears in the display. The envelope icon is indicating one or more unread messages.
The text message is shown in the display, and when the message is read the envelope icon will disappear.
If the message contains a call-back number, this will be displayed on the bottom line of the display. As long as the call-back number is in the display, it is possible to activate the number by pressing the ✆-key.

1st letter in the display, in front of the timestamp, shows the message status: read (R), unread (N) or locked (L). Mails include a maximum of 72 letters or digits (2 display screens of 36 each). Call-back number is max. 24 digits (or letters for E-mail).

14 messages can be ”stored” in the handset. When receiving a new message, the oldest unlocked will be deleted. Locked messages will not automatically be overwritten, but can manually be deleted. Maximum 7 messages can be locked.

8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 36

Read a mail
Press the R-key (MAIL) followed by the ✓-key or enter the Mail Menu (in on hook condition).
If the message includes more than 36 letters or digits, the message will run over 2 display screens.
Use the > -key to scroll. To see the **sender** of the mail, press the ✓-key. To leave the mail, press the MENU-key.

Reply a mail
Open the mail by pressing the R-key followed by the ✓-key, press the ✓-key again and use the < > -keys to find the reply feature, press the ✓-key and you are then able to reply the mail. After writing your reply press the ✓-key to confirm.

Forward a mail
Open the mail by pressing the R-key followed by the ✓-key, press the ✓-key again and use the < > -keys to find the forward feature, press the ✓-key twice and you are then able to write the number on the receiver. Confirm with the ✓-key.

Delete all mail
Open the mail stack by pressing the R-key followed by the ✓-key, press the ✓-key again and use the < > -keys to find the delete feature, press the ✓-key and all mails are deleted.

8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 37

Delete a mail
Open the mail by pressing the R-key followed by the ✓-key, press the ✓-key again and use the < > -keys to find the delete feature, press the ✓-key and the mail is deleted.

Lock/unlock a mail
Open the mail by pressing the R-key followed by the ✓-key, press the ✓-key again and use the < > -keys to find the lock/unlock feature, press the ✓-key and the mail is locked/unlocked.

Write a mail
To write a new mail press the R- key (MAIL), confirm with the ✓-key and write your message. To send the mail press the ✓-key, type the number of the receiver and confirm with the ✓-key.

If one or more mails are stored do as followed: Press the R-key (MAIL) followed by the > -key confirm with the ✓-key and write your message. Press the ✓-key, type the number of the receiver and confirm with the ✓-key. The message is sent.

Note
In case a sent message is not received, the sender will get a message in the display.

8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 38

The Mail Menu (fig)



VoIPon www.voipon.co.uk sales@voipon.co.uk Tel: +44 (0)1245 808195 Fax: +44 (0)1245 808299

8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 39

7.12 Speed dial

Please note: To use the speed dial function it is necessary to set “LONG KEY” to “SPEED DIAL” (see Chap 10).

The speed dial list has maximum 11 speed dial numbers. Calling a number from the speed dial list is done by pressing the 0,1,2...9 key with a long key press or by pressing the alarm button key. If no number is assigned to the key it is possible to enter a new number. The number is added to the speed dial list automatically.

To store a number (max. 23 digits) in the speed dial list press MENU and use the < or > keys to reach the Speed dial Menu. Press ✓ to enter the menu. Use the < or > keys to scroll between the list numbers, enter the number and then confirm with ✓. After storing, the telephone will go back to standby mode.

To delete or change a number in the speed dial list press MENU and use the < or > keys to reach the Speed dial Menu. Press ✓ to enter the menu. Use the < or > keys to scroll between the list numbers, press ✓ to select the number in question and then use the < key to delete the existing number. Confirm with ✓ or enter a new number and then confirm with ✓.

8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 40

8. Date and Time Function

The Date and Time function requires the use of a KIRK Wireless Server and special software in the main system. If the Date and Time function is supported, a clock is shown in the 1st line of the display. The clock shows the time with an accuracy of +/- 1 minute.

If the Date and Time function is supported, then date and time of the incoming or outgoing call is also shown in the CLIP/Redial stack on the 4th line of the display. An icon + date and time shows the status of the call.

If the call is missed, the date and time is displayed: ✕ 29/03 20:28
If the incoming call is received, the date and time is displayed: ➔ 29/03 20:28
If the outgoing call is made, the date and time is displayed: 29/03 20:28 ➔

Date and time is only displayed if CLIP feature is supported by the PBX.

VoIPon www.voipon.co.uk sales@voipon.co.uk Tel: +44 (0)1245 808195 Fax: +44 (0)1245 808299

8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 41

9. Language

There are 10 predefined languages in the handset: English, German, French, Italian, Spanish, Dutch, Portuguese, Swedish, Danish and Norwegian. Select the required language by pressing the ✓-key. If an 11th language is present this will be shown. This language is a specific dealer language and is factory programmed.



8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 42

10. Advanced settings

AUTO HOOK: Can be turned on/off using < and >. Confirm with ✓. When turned on, the handset automatically goes off hook when removed from the charger and a call is present. When placing the handset in the charger, the handset automatically goes on hook.

ANY KEY ANSW: Can be turned on/off using < and >. Confirm with ✓. When turned on, all keys work as a Hook key when receiving an incoming call.

LONG KEY: Can be set to “SEND MSF” or “SPEED DIAL” using < and >. Confirm with ✓. When choosing “SEND MSF” an MSF is sent to the KIRK Wireless Server when pressing 0,1,2...9 with a long key press or when pressing the alarm key with a long key press. When choosing “SPEED DIAL” a call is made to the assigned number when pressing 0,1,2...9 with a long key press or when pressing the alarm key with a long key press. If no number is assigned the alarm key it is possible to enter a new number. This number is automacally added to the speed dial list. For more information, see Chap 7.12.

LONG KEY TIM: Used to define the time for how long a key (0,1,2...9) should be pressed before it is detected as a long key press.

VoIPon www.voipon.co.uk sales@voipon.co.uk Tel: +44 (0)1245 808195 Fax: +44 (0)1245 808299

8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 43

A. KEY DELAY: Used to define the time for how long the alarm key should be pressed before the alarm key function is executed.

LS ON B-ANSWER: Can be turned on/off using < and >. Confirm with ✓. When turned on and "B-ANSWER ON" (hands-free) is selected, the handset turns on the loudspeaker automatically (see Chap. 7.4). (Loudspeaker only works on KIRK 4040).

STANDBY TEXT: Can be turned on/off using < and >. Confirm with ✓. When turned off the display shows a local stand-by text.

HEADS. ALERT: The ringer volume in headset can be set to either "OFF" or 1, 2, 3, 4, 5 (indicated by a bar) using < and >. Confirm with ✓. (only works on KIRK 4040).

HEADSET VOL: The volume in headset can be set to either 1, 2, 3, 4 or 5 (indicated by a bar) using < and >. Confirm with ✓. (only works on KIRK 4040).

OFF HOOK MSF: Can be set to either "NORMAL", "KEY CLICK" or "KEY BEEP" using < and >. Confirm with ✓. The "OFF HOOK MSF" setting only applies to the behaviour of the handset when an MSF is received and the handset is off hook. When set to "NORMAL" the alert type used is the one defined in the MSF. When set to "KEY CLICK" a key click is produced when receiving an MSF. When set to "KEY BEEP" a key beep is produced when receiving an MSF.

8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 44

Advanced settings (fig)



8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 45

11. Shortcuts

”KEY LOCKED”: Press: MENU ✱. (Display shows 🔑)
”SILENT”: Press: MENU #. (No sounds) (Display shows ✍)
“PHONE BOOK”: Press > (BOOK) in standby
Name search in telephone book: Press the first letter in name and > (BOOK) afterwards
Store a number: Press > (BOOK) after the number (in on hook)
“REDIAL ”and “CLIP”: Press < (REDIAL) in standby
“MAIL”: Press R (MAIL) in on hook
MUTE temporarily the ringer: Press ✓ (MUTE) when the telephone is ringing
MUTE the microphone: Press ✓ (MUTE) when the telephone is off hook
RECALL: Press the INT-key if residential system, else press the R-key
Pause(-): Hold * for one second
Change from pulse to DTMF(T): Hold ✱ for 2 seconds

8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 46

12. Information

12.1 Error tree

Problem	Check
The telephone freezes	Remove and replace the battery pack. Press ☎ to turn on the telephone
The telephone does not ring	Check whether the ringer is SILENT or RINGER VOL. is OFF
The telephone cannot find a system ID at "SUBSCRIPTION CREATE"	Check whether the system is set to allow subscriptions
The telephone cannot subscribe even if system ID has been found	Check if Access Code is necessary
Not possible to turn on the telephone	Check if battery is connected. If yes, charge the battery
The telephone turn off when recieving a call and going off-hook	Charge the battery. If still a problem change the battery as it might be defective

VoIPon www.voipon.co.uk sales@voipon.co.uk Tel: +44 (0)1245 808195 Fax: +44 (0)1245 808299

8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 47

12.2 Error information

Improper function of the handset might be related to the installation of the KIRK solution or failures related to the main system. Before declaring a handset for repair be sure that the main system is operating properly.

12.3 Warranty

The handset is covered by a normal warranty-solution, except the battery. The lifetime of the battery depends on the general use of the handset.

The handset is not covered by a general warranty if:

- The handset is exposed to water or metal dust
- The handset is mistreated
- The handset is exposed to unauthorised break-in

VoIPon www.voipon.co.uk sales@voipon.co.uk Tel: +44 (0)1245 808195 Fax: +44 (0)1245 808299

8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 48

12.4. Technical information

Approvals

Acoustics:	TBR 10
Electrical/DECT RF:	EN 301 406
Access profile:	TBR 22 (GAP)
EMC:	EN 301 489 -1/-6
Safety:	EN 60950-1:2001 + A11:2004 + Corrigendum:2004 EN 50360:2001

Size and weight

Size:	149 x 50 x 28 mm
Weight:	123 g including battery ± 10 g

Capacity

Active talking time	12 hours
Stand-by time	150 hours

VoIPon www.voipon.co.uk sales@voipon.co.uk Tel: +44 (0)1245 808195 Fax: +44 (0)1245 808299

8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 49

12.5. Product information



The product must not be disposed of with unsorted waste, but must be collected separately.

Please find the EC Declaration of Conformity at http://www.kirktelecom.com/company/suk242.asp

8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 49

8566_1408 8700_ed5.qxp 05/12/05 12:02 Side 50